


**FECHO TOQUE RO-82**  
PUSH-TO-CLOSE LATCH RO-82  
CIERRE A PRESIÓN RO-82  
FERMETURE À PRESSION RO-82

**1 PORTA**  
1 DOOR  
**1 PUERTA**  
1 PORTE



**COMPONENTES/ COMPONENTS/ COMPONENTES/ COMPOSANTS**


**Incluso no Kit/ Included in the Kit/ Incluido en el Kit/ Inclus dans le Kit**



**TRILHO SUPERIOR/ TOP TRACK/ RIEL SUPERIOR/ RAIL SUPÉRIEUR**



RM 003



**Sistemas compatíveis/ Compatible systems**  
**Sistemas compatibles/ Systèmes compatibles**

**RO-82 Max**  
(Utilização do amortecimento no fechamento)

RO-82 Max  
(Use of damping in the closing)

RO-82 Max  
(Use of amortiguación en el cierre)

RO-82 Max  
(Utilisation de l'amortissement à la fermeture)

**RO-82 Standard**  
(Utilização do amortecimento no fechamento)

RO-82 Standard  
(Use of damping in the closing)

RO-82 Standard  
(Use of amortiguación en el cierre)

RO-82 Standard  
(Utilisation de l'amortissement à la fermeture)

**RO-82 Basic**  
RO-82 Basic  
RO-82 Basic  
RO-82 Basic



# 1 Medidas para instalação

## Installation dimensions



## Medidas para la instalación

## Dimensions pour l'installation

**Com FS-8002**  
With FS-8002  
Con FS-8002  
Avec FS-8002



**Com FE-9009**  
With FE-9009  
Con FE-9009  
Avec FE-9009



**Legenda/ Legend/ Leyenda/ Légende**

**VM = Vão do Móvel LP = Largura da Porta VT = Vão Total VI = Vão Interno**

**VM = Cabinet Opening LP = Door Width VT = Total Opening VI = Internal Opening**

**VM = Vano del Mueble LP = Ancho de la Puerta VT = Vano Total VI = Hueco Interno**

**VM = Ouverture du Meuble LP = Largeur de la Porte VT = Ouverture Totale**

**VI = Ouverture Interne**

**\*Valores em milímetros/ Values in millimeters**

**Valores en milímetros/ Valeurs en millimètres**


2

## Instalação no trilho

Installation on the track

Instalación en el riel

Installation sur le rail



**Atentar para correto posicionamento do carro acionador**

Ensure correct positioning of the drive carriage

Prestar atención a la correcta colocación del carro accionador

Veiller au bon positionnement du chariot actionneur


3

## Fixe o fecho toque

Fix the touch latch

Fije el cierre de toque

Fixez le loqueteau à pression





**Fixe no trilho**

Fix to the track

Fije en el riel

Fixez sur le rail



**ROMETAL**

Unidade Sistemas

Rodovia BR 470, Km 174,5, nº 4075

Bairro Universal | Veranópolis

RS | Brasil | CEP 95330-000

[www.rometal.com.br](http://www.rometal.com.br)

Unidade Alumínio

Estrada Velha da Vacaria, nº 1339

Bairro Sapopema | Veranópolis

RS | Brasil | CEP 95330-000